

Fw-190A-5/A-6/A-7 Bottom Fuselage Panel with Small Oval Cover
For Eduard 1/48 kits

48003

This is simply one-piece upgrade for Eduard kits. Contains bottom fuselage panel with small oval access cover, the detail almost always omitted in plastic kits and scale plans.

It's accurate shape, dimensions and asymmetrical (yes, it's correct!) location has been captured in this small resin insert. Probably for the first time on scale model or upgrade set.

Installation is easy and need no special comments. Just look at attached photos.

You have only cut-off rear bottom wing part along panel line and replace fragment with our part.

Use minimal amounts of 5-minute epoxy for initial joining resin parts with plastic.

Apply only smallest drops on inside of original wing. If you feel that everything is in right place let epoxy harden (at least 20 minutes), and reinforce joint with low viscosity cyanoacrylate applied on inside.

Modified & engraved by Franek Strzelczyk

High resolution photos at: www.polimedia.pl/apm

Work like with usual resin parts: Use dust mask to protect respiratory system. Wet sanding is recommended. Avoid contact resin dust with eyes and (prolonged) with skin. May cause irritation or sensitization. Disposable gloves and safety goggles are recommended. Before painting degrease surface with Testors Plastic-Prep or pure benzine (petroleum ether). **Do not use paint thinner or gasoline. Do not use benzine to degreasing styrene plastic parts.**

Prime with good plastic primer (Mr.Hobby: Mr. Resin Primer, Mr.Surfacer 1000), automotive plastic primer or good enamel paint. Join parts with medium viscosity cyanoacrylate and 5-minute epoxy glue.

Always work in well ventilated area. Take caution when handling with flammable materials.



Fw-190A-5/A-6/A-7 Bottom Fuselage Panel with Small Oval Cover
For Eduard 1/48 kits

48003

This is simply one-piece upgrade for Eduard kits. Contains bottom fuselage panel with small oval access cover, the detail almost always omitted in plastic kits and scale plans.

It's accurate shape, dimensions and asymmetrical (yes, it's correct!) location has been captured in this small resin insert. Probably for the first time on scale model or upgrade set.

Installation is easy and need no special comments. Just look at attached photos.

You have only cut-off rear bottom wing part along panel line and replace fragment with our part.

Use minimal amounts of 5-minute epoxy for initial joining resin parts with plastic.

Apply only smallest drops on inside of original wing. If you feel that everything is in right place let epoxy harden (at least 20 minutes), and reinforce joint with low viscosity cyanoacrylate applied on inside.

Modified & engraved by Franek Strzelczyk

High resolution photos at: www.polimedia.pl/apm

Work like with usual resin parts: Use dust mask to protect respiratory system. Wet sanding is recommended. Avoid contact resin dust with eyes and (prolonged) with skin. May cause irritation or sensitization. Disposable gloves and safety goggles are recommended. Before painting degrease surface with Testors Plastic-Prep or pure benzine (petroleum ether). **Do not use paint thinner or gasoline. Do not use benzine to degreasing styrene plastic parts.**

Prime with good plastic primer (Mr.Hobby: Mr. Resin Primer, Mr.Surfacer 1000), automotive plastic primer or good enamel paint. Join parts with medium viscosity cyanoacrylate and 5-minute epoxy glue.

Always work in well ventilated area. Take caution when handling with flammable materials.

